

# OPERATORS' MANUAL

## INVERTER MIG Arc Welding Machine

ISO9001:2000

# ***MULTIMIG series inverter***



**IMPORTANT: Read this Owner's Manual Completely** before attempting to use this equipment. Save this manual and keep it handy for quick reference. Pay particular attention to the safety instructions we have provided for your protection. Contact your distributor if you do not fully understand this manual.

## CONTENT

<b>§ 1 Safety .....</b>	<b>1</b>
§1.1 Signal Explanation.....	1
§1.2 Arc Welding Damage.....	1
§1.3 The knowledge of Electric and Magnetic Fields .....	5
<b>§2 Overview.....</b>	<b>7</b>
§2.1 Brief Introduction.....	7
§2.2 Working Principle.....	8
§2.3 Volt-Ampere Characteristic.....	8
<b>§3 Installation and Adjustment .....</b>	<b>10</b>
§3.1 Parameters .....	10
§3.2 Duty cycle and Over-heat.....	11
§3.3 Equipment Connection.....	11
<b>§4 Operation.....</b>	<b>15</b>
§4.1 Layout for the front and rear panel .....	15
§4.2 Welding operation.....	17
§4.3 Welding parameters.....	18
§4.4 Operation environment .....	18
§4.5 Operation Notices .....	19
<b>§5 Maintenance &amp; Troubleshooting .....</b>	<b>20</b>
§5.1 Maintenance .....	20
§5.2 Troubleshooting .....	21
§5.3 Electrical schematic drawing.....	22

## § 1 Safety


### §1.1 Signal Explanation



• The above signals mean warning! Notice! Running parts and getting an electric shock or thermal parts will take damage for your body or others. The corresponding notices are as follows. It is quite a safe operation after taking several necessary protection measures.

### §1.2 Arc Welding Damage

- The following signals and word explanations are to some damages for your body or others happening on the welding operation. While seeing these, please remind of yourself or others to be dangerous.
- Only ones who are trained professionally can install, debug, operate, maintain and repair the equipment.
- During the operation, non-concerned people should be lift, especially for children.
- After shut off the machine power, please maintain and examine the equipment according to §5 because of the DC voltage existing in the electrolytic capacitors.



**ELECTRIC SHOCK CAN KILL.**

- Never touch electrical parts.
- Wear dry, hole-free gloves and clothes to insulate yourself.
- Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.
- Take carefully when using the equipment in small place, falling-off and wet circumstance.
- Never close the machine power before installation and adjustment.

Ensure to install the equipment correctly and ground the work or metal to be welded to a good electrical (earth) ground according the operation manual.

- The electrode and work (or ground) circuits are electrically “hot” when the welder is on. Do not touch these “hot” parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically “hot”.
- Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- Never dip the electrode in water for cooling.
- Never simultaneously touch electrically “hot” parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- When working above the floor level, use a safety belt to protect yourself from a fall should you get a shock.




### **FUMES AND GASES CAN BE DANGEROUS.**

- Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. When welding with electrodes which require special ventilation such as stainless or hard facing or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and below Threshold Limit Values using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.
- Do not weld in locations near chlorinated hydrocarbon vapors coming from

degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.

- Shielded gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the material safety data sheet and follow your employer's safety practices.



### **ARC RAYS CAN BURN.**

- Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding.
- Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- Protect other nearby personnel with suitable, non-flammable screening and /or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.



### **SELF-PROTECTION**

- Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.
- Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.



**DO NOT** add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting.

Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.



**WELDING SPARKS can cause fire or explosion.**

- Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situation.
- When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been “cleaned”.
- Vent hollow castings or containers before heating, cutting or welding. They may explode.
- Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuff less trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.

**Rotating parts may be dangerous.**

- Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- Cylinders should be located:
  - Away from areas where they may be struck or subjected to physical damage.
  - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- Never allow the electrode, electrode holder or any other electrically “hot” parts to touch a cylinder.
- Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.

### **§1.3 The knowledge of Electric and Magnetic Fields**

Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). The discussion on the effect of EMF is ongoing all the world. Up to now, no material evidences show that EMF may have effects on health. However, the research on damage of EMF is still ongoing. Before any conclusion, we should minimize exposure to EMF as few as possible.

In order to minimize EMF, we should use the following procedures:

- Route the electrode and work cables together – Secure them with tape when possible.
- All cables should be put away and far from the operator.

- Never coil the power cable around your body.
- Make sure welding machine and power cable to be far away from the operator as far as possible according to the actual circumstance.
- Connect the work cable to the workpiece as close as possible to the area being welded.
- The people with heart-pacemaker should be away from the welding area.



## §2 Overview

### §2.1 Brief Introduction

MIG SERIES arc welding machine adopts the latest pulse width modulation (PWM) technology and insulated gate bipolar transistor (IGBT) power module, which can change work frequency to medium frequency so as to replace the traditional hulking work frequency transformer with the cabinet medium frequency transformer. Thus, it is characterized with portable, small size, light weight, low consumption and etc.

MIG SERIES arc welding machine uses Mix gas as shielded gas to realize gas shielded welding, active gas ( $\text{Ar}+\text{O}_2$ 、 $\text{Ar}+\text{CO}_2$ ) as shielded gas to realize MAG welding and inactive gas ( $\text{Ar}$ ) as shielded gas to realize MIG welding.

MIG SERIES arc welding machine has automatic protection functions with intelligent to over-voltage, over-current and over-heat. If any one of the above problems happens, the alarm lamp on the front panel will be lighted and output current will be shut off automatically to protect itself and prolong the equipment using life.

MIG SERIES Features:

1. Digital control system, real-time display the welding parameters;
2. High performance multifunction power source (MMA/MIG/MAG);
3. Waveform control, stable welding arc;
4. IGBT technology, low power dissipation;
5. Rated duty circle is 40%(40℃).

MULTIMIG 160/200 has another feature: Synergic control of the welding current and voltage.


MIG SERIES arc welding machine is suitable for all positions welding for various plates made of stainless steel, carbon steel, alloyed steel, copper, titanium, etc, which is also applied to pipe installment, mould mend, petrochemical, architecture decoration, car repair, bicycle, handicraft and common manufacture.

MAG--Metal Active Gas Welding

MIG--Metal Inert Gas Welding

## §2.2 Working Principle


The working principle of MIG SERIES arc welding machine is shown as the following figure. Single-phase 220V work frequency AC is rectified into DC (350V), then is converted to medium frequency AC (about 40KHz) by inverter device (IGBT), after reducing voltage by medium transformer (the main transformer) and rectifying by medium frequency rectifier (fast recovery diodes), and is outputted by inductance filtering. The circuit adopts current feedback control technology to insure current output stably when MMA or TIG. And adopts voltage feedback control technology to insure voltage output stably when MIG. Meanwhile, the welding current parameter can be adjusted continuously and infinitely to meet with the requirements of welding craft.




## §2.3 Volt-Ampere Characteristic

MIG SERIES welding machine has an excellent volt-ampere characteristic, whose graph is shown as the following figure. The relation between the rated loading voltage  $U_2$  and welding current  $I_2$  is as follows:

$$U_2 = 14 + 0.05I_2 (\text{V})$$



## §2.4 Principles of welding



## §3 Installation and Adjustment

### §3.1 Parameters


Parameters Model	MultiMIG200 PFC MV SYN					
Input Voltage (V)	1~110/120/130±10%			1~220/230/240±10%		
Input Current (A)	MIG 37.8	MMA 32	TIG 29	MIG 29	MMA 30	TIG 20
Input Power (KW)	MIG 4.0	MMA 3.5	TIG 3.2	MIG 6.2	MMA 6.2	TIG 4.2
Welding Current (A)	40-200					
No-load Voltage (V)	65					
Duty cycle (40℃)	35% 140A 60% 110A 100% 85A	30% 110A 60% 80A 100% 65A	40% 150A 60% 125A 100% 95A	30% 200A 60% 145A 100% 110A	25% 200A 60% 130A 100% 100A	35% 200A 60% 155A 100% 120A
Diameter(mm)	Fe: 0.6/0.9/1.0 Ss: 0.8/0.9/ 1.0 Flux-Cored: 0.6/0.8/0.9/1.0					
Protection class	IP23					
Insulation class	H					
Dimensions (mm)	511*213*400					
Weight (Kg)	15					
Parameters Model	MultiMIG250 PFC MV SYN					
Input Voltage (V)	1~110/120/130±10%			1~220/230/240±10%		
Input Current (A)	MIG 42	MMA 40	TIG 26.5	MIG 37	MMA 41	TIG 28.5
Input Power (KW)	MIG 4.6	MMA 4.2	TIG 3.0	MIG 8.3	MMA 9.2	TIG 6.4
Welding Current (A)	40-200					
No-load Voltage (V)	65					
Duty cycle (40℃)	30% 160A 60% 115A 100% 90A	35% 130A 60% 100A 100% 80A	35% 140A 60% 110A 100% 85A	35% 250A 60% 195A 100% 150A	30% 250A 60% 180A 100% 140A	35% 250A 60% 195A 100% 150A
Diameter(mm)	Fe: 0.6/0.9/1.0 Ss: 0.8/0.9/ 1.0 Flux-Cored: 0.6/0.8/0.9/1.0					
Protection class	IP23					
Insulation class	H					
Dimensions (mm)	618*240*445					
Weight (Kg)	23					

**Note: The above parameters are subject to change with the improvement of machines.**

### §3.2 Duty cycle and Over-heat

The letter “X” stands for the duty cycle, which is defined as the proportion of the time that a machine can work continuously within a certain time (10 minutes). The rated duty cycle means the proportion of the time that a machine can work continuously within 10 minutes when it outputs the rated welding current.

The relation between the duty cycle “X” and the output welding current “I” is shown as the right figure.



If transformer is over-heat, the heat relay inside it will open and will output an instruction to circuit board, cut AC relay and the output welding current, and brighten the over-heat pilot lamp in the front panel. At this time, the machine should be relaxed for 15 minutes to cool the fan. When operating the machine again, the welding output current or the duty cycle should be reduced.

### §3.3 Equipment Connection


Operation Steps:

- 1、Connect the power source input cable of welding machine with the output port of air switch in electric box on the spot.
- 2、Connect the cable plug of wire feeder to the positive output of welding machine.
- 3、Connect the control cable plug of wire feeder to the aero socket on the front board of welding machine.

- 4、 Connect the negative pole of welding machine to the work piece (base metal).
  - .
  - 5、 Connect the output pipe of gas cylinder to the input joint of gas valve on the wire feeder and clamp it.
  - 6、 Insert the torch joint into the output of wire feeder unit and keep the wire aim at the wire feeder mouth.
- Note: The plane of the joint should be aimed at screw, plugged tightly and rotated 90°, then screw the bolt tightly to ensure the gun contacting closely.
- 7、 Connect the shielded gas pipe of torch with the output of front panel on wire feeder.
  - 8、 Connect the control cable pin of torch with the two-lead aero socket of front panel on wire feeder.
  - 9、 Notice that the wire diameter should be accordant with the wire wheel and torch tip and press the wire properly with the handle.

### §3.4 Maintenance of MIG Gun mechanism

#### §3.4.1 Dissection graphics for the MIG GUN



#### §3.4.2 The parts list for the MIG GUN

NO.	Description	QTY.	Remark
1	Tip D.12 14-15AK	1	

## OPERATION

2	Electric nozzle 0.8/M6*25	1	
3	15AK Goose gun neck (Hexangular adapter and Plastic adapter)	1	
3.1	15AK Goose gun	1	
4	Hexangular adapter	1	
5	Plastic adapter	1	
6	MIG blue handle	1	
7	Torch Switch 21.8mm	1	
8	Screw D.3*10	3	
9	Handle locking ring	1	
10	Cable fixing joint 15AK	1	
11	Coaxial cable team /16mmq/3m	1	
12	Cable thimble 12-16-25 MMQ	1	
13	CO <sub>2</sub> Euro-rear thimble	1	
14	Screw M4*6 UNI 6107	1	
15	Torch locknut /plastic screw thread	1	
16	Euro-main socket/flexibility pin	1	
17	Feeding pipe locknut	1	
18	Insulating feed pipe 0.6-0.8 3m, Blue	1	
19	Spanner for the electric nozzle	1	

### §3.4.3 The operation for the MIG GUN

1. Service the wire feed mechanism at least every time the reel is changed.

- Check the wear of the feed roll groove and change the feed roll when necessary.
- Clean the welding gun wire guide with compressed air.

2. Cleaning the wire guide

Pressure of the feed rolls remove metal dust from the filler wire's surface which then finds its way to the wire guide. If the wire guide is not cleaned, it gradually clogs up and causes wire feed malfunctions. Clean the wire guide in the following manner:

Remove the welding gun's gas nozzle, contact tip and contact tip's adapter.

With a pneumatic pistol, blow compressed air through the wire guide.

Blow the wire feed mechanism and reel housing clean with compressed air.

Reattach the welding gun's parts. Tighten the contact tip and contact tip's adapter to spanner tightness.

### 3. Changing the wire guide

If the wire guide is too worn or totally clogged, change it to a new one according to the following instructions.

Open the mounting nut of the wire guide which exposes the end of the wire guide.

Straighten the welding gun's cable and withdraw the wire guide from the gun.

Push a new wire guide in to the gun. Make sure that the wire guide enters all the way into the contact tip's adapter and that there is an O-ring at the machine-end of the guide.

Tighten the wire guide in place with the mounting nut.


Cut the wire guide 2mm from the mounting nut and file the sharp edges of the cut round.

Reattach the gun in place and tighten the parts to spanner tightness.



## §4 Operation

### §4.1 Layout for the front and rear panel



1. Welding current knob: Set the welding current.
2. Alarm Led: When the welder is over voltage, less voltage, over current or over heated, the alarm pilot lamp will be on.
3. Power Led: Power led is lighted when open the machine.
4. Current display: Welding Current display when machine is working, Set current display before welding. Unit: A.
5. Wire speed LED: You can use current setting knob to set the wire speed when the wire speed LED is on(MIG).
6. Current LED: When the current LED is on, it display the actual output welding current(MIG).
7. Welding voltage/Down slope/Arc force knob: On MIG, When the program voltage can't perfectly match the welding current, the knob can adjust voltage On TIG, the knob can adjust the current down time. On MMA, the knob can adjust the force current.
8. Voltage display: Welding voltage display when machine is working, Set voltage display when MIG mode before welding. Unit: V.
9. Wave control knob: Controls arc characteristics, Determines the rate at which the amperage rises when a short circuit is produced.
10. Spool Gun Switch: You can control the spool gun function active(ON) or not(OFF), at the same time ,you must make the Switch 14 in "ON" mode;
11. Remote Switch
12. Manual wire switch & air check switch: up for manual wire and down for air check.
13. Polarity conversion: connect to "+", the MIG gun connector will be "+", connect to "-", the MIG gun connector will be "-";
14. TIG GAS Connect.
15. Output anode: When TIG mode, this polarity must connect the work piece
16. MIG GUN Connect.

- 17. TIG gun control connector.
- 18. Output cathode: When MIG mode, this polarity must connect the work piece
- 19. Burnback knob
- 20. Slow feed knob
- 21. Post flow knob
- 22. Pre-flow knob

## §4.2 Welding operation

**For example MULTIMIG 200**

### §4.2.1 MIG mode operation:

#### 1. Shielding Gas choice

- 1) When the wire material is Fe, the shielding gas is 80%Ar + 20%CO<sub>2</sub> ;
- 2) When the wire material is Ss, the shielding gas is 98%Ar + 2%O<sub>2</sub> ;
- 3) When the wire material is Al, the shielding gas is 100%Ar.

#### 2. Welding state choice

- 1) Press the weld manner key, choose MIG manner and the MIG LED is lighted;
- 2) Spool Gun Switch turn off(down).
- 3) Manual wire switch & air check switch, Burnback adjust, Slow feed adjust, Post flow adjust, Pre-flow knob adjust;
- 3) Press the welding mode key, choose 2T or 4T;
- 4) Spool Gun Switch turn on(up):

#### 3. Adjust Welding parameter

- 1) Different wire diameter ,the minimum welding current is different;
- 2) Adjust the current knob , the corresponding welding voltage is changed automatically;
- 3) When the programmable welding voltage isn't the perfect for the operator, the voltage

can be changed finely by adjusted the knob;

4) If the operator adjust the wave control knob, the arc characteristics can be controlled;

#### §4.2.2 TIG mode operation:

1. Press the weld manner key, choose TIG manner and the TIG LED is lighted;
2. Press the welding mode key, choose 2T or 4T;
3. Adjust the current knob to control the welding current;
4. Adjust the down slope knob to control the welding current descend time.

#### §4.2.3 MMA mode operation:

1. Press the weld manner key, choose MMA manner and the MMA LED is lighted;
2. Adjust the current knob to control the welding current;
3. Adjust the welding arc force knob to control the arc force current.

**Note: The current display is preset current before welding and is welding current when welding. The voltage display is real voltage.**

### §4.3 Welding parameters

Wire diameter (mm)	Welding current (A)	Plate thickness (mm)
0.6	25-110	1.0-1.6
0.8	35-160(200)	1.0-2.3
0.9	45-160(200)	1.0-2.3
1.0	45-160(200)	1.2-6

### §4.4 Operation environment

- ▲ Height above sea level  $\leq 1000$  M
- ▲ Operation temperature range  $-10 \sim +40^{\circ}\text{C}$ .
- ▲ Air relative humidity is below 90 % (  $20^{\circ}\text{C}$  ).

- ▲ Preferable site the machine some angles above the floor level, the maximum angle does not exceed 15°C.
- ▲ Protect the machine against heavy rain or in hot circumstance against direct sunshine.
- ▲ The content of dust, acid, corrosive gas in the surrounding air or substance can not exceed normal standard.
- ▲ Take care that there is sufficient ventilation during welding. There is at least 30cm free distance between the machine and wall.

## **§4.5 Operation Notices**

- ▲ Read §1 carefully before attempting to use this equipment.
- ▲ Connect the ground wire with the machine directly and refer to §3.5.
- ▲ Ensure that the input is single-phase:50/60Hz, 220/230/240V  $\pm 10\%$ .
- ▲ Before operation, no concerned people should be left. Do not watch the arc in unprotected eyes.
- ▲ Ensure good ventilation of the machine to improve duty ratio.
- ▲ Turn off the engine when the operation finished for economize energy sources.
- ▲ When power switch shuts off protectively because of failure. Don't restart it until problem is resolved. Otherwise, the range of problem will be extended.
- ▲ In case of problems, contact your local dealer if no our authorized maintenance man.

## §5 Maintenance & Troubleshooting

### §5.1 Maintenance

In order to guarantee that arc welding machine works high-efficiently and in safety, it must be maintained regularly. Let customers understand the maintenance methods and means of arc welding machine more , enable customers to carry on simple examination and safeguarding by oneself, try one's best to reduce the fault rate and repair times of arc welding machine, so as to lengthen service life of arc welding machine .Maintenance items in detail are in the following table.

- **Warning: For safety while maintaining the machine, please shut off the supply power and wait for 5 minutes, until capacity voltage already drop to safe voltage 36V.**

Date	Maintenance items
Daily examination	<p>Observe that whether panel knob and switch in the front and at the back of arc welding machine are flexible and put correctly in place. If the knob has not been put correctly in place, please correct; If you can't correct or fix the knob , please replace immediately;</p> <p>If the switch is not flexible or it can't be put correctly in place, please replace immediately; Please get in touch with maintenance service department if there are no accessories.</p> <p>After turn-on power, watch/listen to that whether the arc welding machine has shaking, whistle calling or peculiar smell. If there is one of the above problems, find out the reason to get rid of; if you can't find out the reason, Please contact local this area agent or the branch company.</p> <p>Observe that whether the display value of LED is intact. If the display number is not intact, please replace the damaged LED. If it still doesn't work, please maintain or replace the display PCB.</p> <p>Observe that whether the min/max value on LED accords with the set value. If there is any difference and it has affected the normal welding craft, please adjust it.</p> <p>Check up that Whether fan is damaged and is normal to rotate or control. If the fan is damaged, please change immediately. If the fan does not rotate after the arc welding machine is overheated , observe that whether there is something blocked in the blade, if it is blocked, please get rid of ; If the fan does not rotate after getting rid of the above problems, you can poke the blade by the rotation direction of fan. If the fan rotates normally, the start capacity should be replaced; If not, change the fan.</p> <p>Observe that whether the fast connector is loose or overheated. if the arc welding machine has the above problems, it should be fastened or changed.</p> <p>Observe that Whether the current output cable is damaged. If it is damaged, it should be wrapped up, insulated or changed.</p>

Monthly examination	<p>Using the dry compressed air to clear the inside of arc welding machine. Especially for clearing up the dusts on radiator, main voltage transformer, inductance, IGBT module, the fast recover diode and PCB, etc.</p> <p>Check up the bolt in arc welding machine, if it is loose, please screw down it. If it is skid, please replace. If it is rusty, please erase rust on bolt to ensure it works well.</p>
Quarter-yearly examination	<p>Whether the actual current accords with the displaying value. If they did not accord, they should be regulated. The actual current value can be measured by the adjusted plier-type ampere meter.</p>
Yearly examination	<p>Measure the insulating impedance among the main circuit, PCB and case, if it below <math>1M\ \Omega</math>, insulation is thought to be damaged and need to change, and need to change or strengthen insulation.</p>

## §5.2 Troubleshooting

- Before arc welding machines are dispatched from the factory, they have already been debugged accurately. So forbid anyone who is not authorized by our company to do any change to the equipment!
- Maintenance course must be operated carefully. If any wire becomes flexible or is misplaced, it maybe potential danger to user!
- Only professional maintenance personal who is authorized by our company could overhaul the machine!
- Guarantee to shut off the arc welding machine's power before turn on the outline of the equipment!
- If there is any problem and has no the authorized professional maintenance personal of our company, please contact our local agent or the branch company!

If there are some simple troubles of MIG SERIES welding machine, you can consult the following Chart:

NO.	Troubles	Reasons	Solution
1	Close the breaker, but the power light isn't on	Breaker damaged	Change it
		Fuse damaged	Change it
		Power damaged	Change it
2	After welding machine is over-heat, the fan doesn't work	Fan damaged	Change it
		The cable is loosen	Screw the cable tightly

MAINTENANCE AND TROUBLESHOOTING

3	Press the gun switch, no output shielded gas	No output gas when test gas	No gas in the gas cylinder	Change it
			Gas pipe leaks gas	Change it
			Electromagnetic valve damaged	Change it
		Output gas when test gas	Control switch damaged	Repair the switch
			Control circuit damaged	Check the board
4	Wire-feeder doesn't work	Wire reel doesn't work	Motor damaged	Check and change it
			Control circuit damaged	Check the board
		Wire reel works	The press wheel is loosen or weld wire skids	Press it tightly again
			The wheel doesn't fit with the diameter of weld wire	Change the wheel
			Wire reel damaged	Change it
			Wire feed pipe is jammed	Repair or change it
			Tip is jammed because of splash	Repair or change it
5	No striking arc and no output voltage	Output cable is connected mistakenly, or loosen		Screw it down or change it
		Control circuit damaged		Check the circuit
6	Welding stops, and alarm light is on	Machine has self-protection		Check over-voltage, over-current, over-temperature, lower-voltage and over-temperature, and solve it
7	Welding current is run away and can be not controlled	The potentiometer damaged		Check or change it
		The control circuit damaged		Check the circuit
8	The crater current can be not adjusted	The PCB damaged		Check it
9	No post-gas	The PCB damaged		Check it

## §5.3Electrical schematic drawing



